



## DAILY CLEANING INSTRUCTIONS

### AT THE START OF THE DAY

#### STEP 1

Turn on machine.  
Wait until all lights  
stop flashing.



#### STEP 2

Follow the set-up instructions that  
are displayed on the screen.

### EVERY FOUR HOURS

#### STEP 1

Remove Autocappuccinatore  
and drip tray. Empty and  
clean the milk canister with  
hot soapy water. Clean the  
Autocappuccinatore with a  
brush to clear the plastic tube.



#### STEP 2

Press the '☕'  
button and allow the  
machine to rinse water.



#### STEP 3

Once rinsing is complete, place the Autocappuccinatore,  
milk canister and drip tray back into the machine.  
A message will display on the screen when the  
machine is ready to use.



### AT THE END OF THE DAY

(OR BEFORE TURNING THE MACHINE OFF)

#### STEP 1

Remove the Autocappuccinatore device  
from the milk canister and steam head.

**NOTE:** The Autocappuccinatore  
must be cleaned every eight (8) hours  
using a brush to clean the plastic tube.



#### STEP 2

Unscrew the steam spout  
(clockwise) and wash with hot  
soapy water. At the same time  
ensure that the steam nozzle is  
unblocked.



#### STEP 3

**IMPORTANT:** Place cup  
underneath and push  
the + button to flush  
milk residue.



#### STEP 4

Turn off the machine. Clean the drip  
tray and milk canister thoroughly with  
hot soapy water. Please wipe surfaces.

**NOTE:** Do not wash drip trays and  
capsule containers in dishwasher.



If you require assistance, please watch the Machine Assistance videos on [www.nespresso.com/pro](http://www.nespresso.com/pro),  
or complete the contact us form on [www.nespresso.com/pro](http://www.nespresso.com/pro) and a Nespresso representative will be in touch.