

RESTARTING YOUR CS20 CAPPUCCINATORE & GEMINI MACHINES AFTER A PERIOD OF STAGNATION

Your health and safety is our first priority. We want to make it easy for you to clean and check that your **Nespresso** Professional coffee machine is running smoothly again after a long time of non-use.



CS20 Cappuccinatore



Gemini

- 1 Dispose of any straws and nozzles left on your machine. Rinse water tanks.
- 2 Plug machine into the wall power outlet and switch on. Switch machine on using the switch on front panel.
- 3 Perform daily cleaning cycle, instructions found in user manual or the Machine Assistance page on the **Nespresso** Professional [website](#).
- 4 As described in the user manual, it is important to remove and clean nozzle with red rings (see picture on the left).
 - a. Use a toothpick or paperclip to clear the small holes on the nozzle for any milk build up.
 - b. Prior to replacing nozzle hold down steam button to observe strong direct steam pressure from the machine. After replacing nozzle again, hold down the steam button to observe strong direct steam pressure from the machine.
- 5 If using an Autocappuccinatore, disassemble all components of Autocappuccinatore and submerge in hot soapy water to remove any milk build up. Use supplied brush, refer to the 'Cleaning of Autocappuccinatore and Accessories' instructions for more information.

