

PROFESSIONAL

ZENIUS MACHINE IN TANK WATER FILTER CARTRIDGE REPLACEMENT PROCEDURE


You may refer to the machine assistance videos on the Nespresso Professional website for guidance.

Optional In-Tank Water Filter (if fitted to Zenius)

If you are using optional in-tank water filters on your Zenius machine, and you are restarting the machine after a period of business shutdown, please replace existing in-tank filter with a new one.

Simply follow the steps to the 'Filter cartridge exchange procedure' below.

Note: Optional in-tank water filters for Zenius machines are not included with new machine and not a part stocked/supplied by **Nespresso** Professional.




Empty water tank.



Remove used water filter cartridge and discard it.




Clean and flush water tank with a soft towel.



Remove the new filter from its packaging.




Using a coin or something similar to a coin, turn the dial anticlockwise.



The window on the dial should begin with the current month e.g. 5 for May. Life time of the filter is 4 months



Insert the water filter cartridge Fill water tank with fresh in the water tank.



potable water and insert in the coffee machine



Dispense 800mL of hot water using the 'Hot Water' button on the machine



Switch off the main power button.




Press and hold 'Hot Water' button while turning on the




Observe blinking cycle on the machine



To select new filter, press 'Ristretto' durina blinkina cycle.



Confirmation of selection: New filter is selected



About 150mL cold water flows out of the hot water outlet within approx. 50 seconds.