


## HOW TO CONFIGURE THE ORDER BUTTON?


Order your favourite coffee capsules directly from your **Eszenza Plus** coffee machine, by just pressing the Order Button. Before its first use, the Order Button needs to be configured (one-time only).

Here's how it works:


- To set it up, make sure Bluetooth and WiFi are enabled on your mobile device and that you are close to your machine.




- Download the **Nespresso** app, or if you have it already, we recommend updating the app to the latest version.




- Launch the app on your smartphone or tablet. From the homepage, click on the machine icon.




- Pair your machine by following the instructions via the app. When the pairing is complete, the Order Button will blink 3 times. If the orange LED is blinking, it means the pairing failed. Restart the pairing process.




- Once your machine is paired, connect your machine to your WiFi network.



- You can now configure an order template by choosing a previous order or create a new one.



- Select the delivery address and the payment method.



## YOUR CONFIGURATION IS COMPLETE

As of now you don't need your phone anymore.

One push of the button, one coffee order.  
It couldn't be easier!

Your coffee order will be delivered straight to your home.

**TIME TO ENJOY MOMENTS OF PURE PLEASURE!**

